



CD系列

使用說明書

產品介紹

CD系列為標準配置的機械鍵盤，採用QWERTY佈局，搭配PBT二射成型鍵帽、德國Cherry MX系列軸體、雙層PCB板並支援全鍵無衝。

包裝內容物

- 鍵盤本體 x1
- 使用說明書 x1
- 防塵蓋 x1
- 拔鍵器 x1
- RGBY 彩色鍵帽

鍵盤規格

- 鍵數：CD87=USASCII(87鍵)=US配置
CD108=USASCII(108鍵)=US配置
- 尺寸：CD87=長 358 x 寬 136 x 高 41.6 mm (鍵盤)
CD108=長 438.5 x 寬 136 x 高 41.6 mm (鍵盤)
- 軸體使用壽命：單顆按鍵5000萬次
- 介面：USB (DC5V----100mA)
- 可用配置：US配列


功能說明

1. 按 Fn + 左 Windows 鍵 = 鎖住兩側 Windows 鍵。
2. 按 Fn + 右 Windows 鍵 = 解鎖兩側 Windows 鍵。
3. 按 Fn + ScrLk = 切換到 6 鍵無衝(預設為全鍵無衝)。
4. 按住 Fn + Delete 3秒後LED指示燈會閃爍三次 = 恢復至原廠設定。
5. 針對CD87，當按下 Fn + F1/F2/F3/F4 = 靜音/小聲/大聲/計算機。


備註

1. 出廠預設值為N-key 全鍵無衝，當切換到6鍵無衝時，LED指示燈會閃爍一次，再次切換到全鍵無衝時，LED指示燈會閃爍三次。

CD87



CD108





CD Series

USER MANUAL

Description:

CD Series is a standard mechanical keyboard. The keyboard layout is QWERTY. All keycap is bundle with PBT double shot, cherry MX switch and N-key Rollover.

Included accessories:

- Keyboard x1
- User manual x1
- Dust cover x1
- Key puller x1
- RGBY Keycap

Specifications:

- Key Layout: CD87=USASCII(87keys)=US
CD108=USASCII(108keys)=US
- Dimensions: CD87=L 358 x W 136 x H 41.6mm
CD108=L 438.5 x W 136 x H 41.6mm
- Key Switch Life Time: 50 millions
- Interface: USB (DC5V----100mA)


Main Function:

1. Turn on WinLock function = Press Fn + L_Win key.
2. Turn off WinLock function = Press Fn + R_Win key.
3. Change (6-key, N-key) Rollover = Press Fn + ScrLk.
4. Keyboard Reset = Press Fn + Delete for 3 seconds, the LED lights will flash 3 times.
5. Specific for CD87. Press Fn + F1/F2/F3/F4 = Mute/Volume down/Volume up/Calculator.

Note:

1. When LED lights flash 1 time = 6-key rollover.
When LED lights flash 3 times = N-key rollover.
*Default setting is N-key rollover.

CD87



CD108

